

HYVOX[®]

SANDWICH MAKER



USER'S MANUAL

Model HI-340

Thank you for purchasing Hyvox Sandwich Maker, from Hyvox Ingenious Home Collection of products. Please read your user's manual carefully as it provides important information regarding safety, operation and maintenance. Please kindly retain this manual and model number for future reference.

Ingenious Home Collection
Changing life concepts!



HYVOX

Thank you.

We appreciate your business. Thank you for purchasing Hyvox Sandwich Maker from the Hyvox Ingenious Home Collection of products.

Changing Life Concepts!

CONTENTS

Sandwich Maker.....	02
Safety Information.....	03
Anatomy of the Sandwich Maker.....	05
Operating instructions.....	06
Suggestions for Best Results.....	08
Care & Cleaning.....	09
Warranty information.....	10

SANDWICH MAKER HI-340

Hyvox brings you another Ingenious Home Collection that will brighten your day with easy sandwich making.

Makes you tasty sandwiches in minutes. Its classy design combined with its high quality, makes it a welcome addition to your creative kitchen. Make sandwiches for parties, school, lunch or snack packs, picnics etc. With a four slice capacity at a time and the capability to accommodate any type of fillings, this is one of the best sandwich makers ever from the Hyvox Ingenious Home Collection.

ADVANTAGEOUS FEATURES

01. 4 bread, 2 sandwich slice capacity.
02. Dishwasher friendly plates.
03. Anti-adhesive layer.
04. Fixed baking temperature.
05. Power control light.
06. Ready light indication.
07. Power 220-240V / 750W.

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, basic precautions mentioned below should be followed.

01. To protect against electric shock, do not immerse cord, plug or sandwich maker into water or any other liquid.
02. Close supervision is necessary when any appliance is used by or near children.
03. Do not use the appliance for unintended use.
04. Unplug from the outlet when not in use and before cleaning the appliance. Allow to cool down before putting on or taking off parts and before cleaning the appliance.
05. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
06. To reduce the risk or injury, use only accessory attachments if recommended by the appliance manufacturer.
07. Do not use outdoors. Do not touch hot surfaces. Use handles or knobs.
08. Do not let cord hang over sharp edges of a table or counter, or touch hot surfaces.
09. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. The bread may burn, therefore do not use the appliance near or below combustible material such as curtains.

SAFETY INSTRUCTIONS cont...

11. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard.
12. This appliance is not intended for use by children or other persons without assistance.
13. Children should be supervised to ensure that they do not play with the appliance.
14. The temperature of accessible surfaces may be high when the appliance is operating.
15. Do not immerse in water or any liquid.
16. This appliance is for household use only. No user serviceable parts inside. Return the appliance to the nearest authorized service center for examination, repair or adjustment.

ANATOMY OF SANDWICH MAKER

Here we explain to you the various parts of the Sandwich Maker.



1 Power-on light (red)

2 Ready light (green)

3 Latch

4 Top toasting plates

5 Bottom toasting plates

6 Handle

OPERATING INSTRUCTIONS

Please follow the instructions below carefully. They contain important sandwich making instructions and guidelines.

01. When using for the first time, wipe the surface of the plates with a piece of damp cloth, dry cloth or tissue.
02. Then smear the plate neatly with butter, margarine or cooking fat oil.
03. Fit the plug into the socket.
04. Close the sandwich maker and prepare sandwich while toaster is heating.
05. When the sandwich maker is ready after about 3 minutes the temperature indicator light (the green one) will be on.
06. Fully open the sandwich maker. Place a slice of bread in the bottom half with the buttered side against the plate.
07. Fill the sandwich, pressing the bottom half into the plate.
08. Place a slice of bread in the top half with the buttered side up and carefully close the two parts of the toaster together.
09. Do not force shut – steam will be ejected from the opening between the plates while making sandwiches – care must be taken to ensure the fingers do not come into contact with hot surface and steam.
10. Lock the two half with the latch while toasting is taking place.

OPERATING INSTRUCTIONS cont...

11. During toasting, the temperature indicator light will cycle on and off while the thermostat keeps the appliance at the right temperature – cook only with metal plates closed.
12. Your sandwich will be toasted in 2-3 minutes or longer to suit your taste. Open the toaster and remove the sandwich using plastic or wooden spatula – never use metal knife as this may damage the non-sticking coating.
13. Close the lid to preserve the heat until ready to toast the next sandwich.
14. Prepare further sandwiches if required while one is being cooked.
15. After use, remove the plug from the socket.

SUGGESTIONS FOR BEST RESULTS

You may come up with your own way of making sandwiches as long as it does not tamper the unit, however we offer you some suggestions.

01. Always preheat before use – plug in socket outlet while preparing the fillings.
02. For soft or liquid sandwich fillings, use medium slice or bread, white or brown. If small amounts of filling, use toasted bread.
03. Flavored butter may also be used.
04. For added flavor use bacon dripping, brush the dripping on the outside surface of the bread.
05. Suggested garnishes for savory sandwiches: lettuce, mint, cress, stuffed olive halves onion, tomato, etc.
06. A teaspoon of sugar sprinkled on the outside surface of bread makes the sandwich crisper (especially with fruit fillings.)

CARE & CLEANING

If servicing is needed, take it to our service centre. Do not try to repair it. There are no user serviceable parts.

01. After use and before cleaning, remove the plug from the socket and wait for the appliance to cool down.
02. Wipe the inside and the edges of the plates with kitchen roll, absorbent paper towel or a soft cloth.
03. Should any filling be difficult to remove, pour a little cooking oil onto the plate and wipe off after 5 minutes when the filling is softened.
04. Wipe the outside with only a slightly moistened cloth to ensure that no moisture, oil or grease enter the cooling slots.
05. Do not clean the inside and outside surface with any abrasive scouring pad or steel wool as this will damage the finish.
06. Use only water or recommended liquid to clean the appliance. Do not use any other chemical solution to clean the appliance.

WARRANTY INFORMATION

This warranty covers only manufacturer defectives for one year, with the exceptions stated below.

What Is Not Covered

This warranty does not cover any damage caused due to physical abuse of the product by misuse or use other than as intended and described in the instruction manual, or damage caused by failure to properly clean and maintain this product or damages caused by natural disaster or acts of war. The warranty is voided if connected to any voltage or specifications other than prescribed on the product. Also, if the unit is opened for self repair, the warranty will be void for any further repair or problem analysis. The warranty may not be used if the product is served in public places such as lodging house, training centres etc. Warranty does not cover any shipping and handling charges. Hyvox Inc. deserves the right to refuse any warranty claim without any valid reasons.

What Will We Do

Should you detect any malfunction, please return the damaged product along with the purchase receipt with a brief explanation of the problem, either directly to a distributor of Hyvox products near you or to the shop you had purchased from. We will repair any defects in materials or workmanship within one year of purchase. If the defective is found un-repairable within the warranty period, Hyvox with its discretion will replace it for a new unit. However, Hyvox reserves complete rights in decision making in regards to processing the warranty, rejecting any claim without any valid reason or arranging a replacement.

If you have any questions, please feel free to contact our customer service e-mail or our local distributors near you. Please visit www.hyvox.com to find a local distributor near you.

Find more Hyvox Ingenious Home Collection products at

www.hyvox.com

Changing life concepts!

Send us your valuable suggestions and feedback.
Login to www.hyvox.com.

You can also find a copy of this document for download and other supportive materials on our website. Thank you once again for purchasing Hyvox Sandwich Maker, your Ingenious Home Collection.

HYVOX[®]

Ingenious Home Collection
Changing life concepts!

Hyvox Inc.
Mississauga, Ontario
Canada

info@hyvox.com
www.hyvox.com

'Hyvox' brand name and logo, 'Ingenious Home Collection' and 'Changing life concepts!' are registered trademarks of Hyvox Inc., Ontario, Canada.

Copyright © Hyvox Inc. 2005. E&OE.